

Claytonrite Weatherstrip Glazing Seals



INSTALLATION GUIDE

Use the Claytonrite Filler Strip Insertion Tool (Item Code: ACC009) to remove the existing filler strip.

Prise the window out of the existing seal carefully, making sure not to cause any damage.

Remove the existing window seal and clean the area as this will improve the performance and lifespan of the new seal.

Fit the new Claytonrite seal around the empty window opening, ensuring it is pushed tight into the corners.

Cut the seal 25mm beyond the join, ensuring the cut is square to ensure a tight butt joint.

Remove the seal and then apply a small bead of silicone sealant into the groove.

Refit the seal around the empty window opening, making sure the butt joint is at the top.

Apply a small bead of silicone into the window groove.

Push the window back into the seal from the bottom. Use the Claytonrite Filler Strip Insertion Tool to work the lip of the seal over the window.

Brush a lubricant into the whole of the filler strip channel.

Starting from the bottom, insert the head of the Claytonrite Filler Strip Insertion Tool into the channel.

Feed the filler strip through the head of the Claytonrite Filler Strip Insertion Tool.

Push the Claytonrite Filler Strip Insertion Tool along the filler strip channel - the filler strip will be installed and secured into the seal as you go around. Ensure the filler strip isn't stretched at all as, over time, it will shrink back and affect the performance.

Once you've reached the join, cut the filler strip with a slight overhang of a few millimetres.

Push the cut end of the filler strip into the filler strip channel, making a tight butt joint with the other end.