

SafaWood Anti-Slip Decking Boards



INSTALLATION GUIDE

Fixing

We recommend SafaWood is face-fixed with 2 x 63mm stainless steel or coated deck screws per each joist. The screws should be driven down below the surface of the rubber, which will hide the screw head and provide maximum hold.

The fixing points should be a minimum of 15mm from the end and a minimum of 20mm from the edge.

The supports should be set at a maximum of 450mm centres.

A spacing of 5mm to 6mm should be allowed between the boards.

A slight fall should be incorporated into the design / installation to help improve drainage. We recommend a fall of 1% (1:100). For example, the deck should slope by 10mm for every 1m of length.

If SafaWood boards are to be cut, the sawn ends should be retreated with a timber preservative.

Maintenance

Regular cleaning with a mild detergent, together with treatment of exposed timber components will help to maintain SafaWood decking.

SafaWood can be cleaned using a jet washer at a pressure up to 1500psi.